

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
 North Las Vegas, NV 89031
 TEL: 702-399-1423
 FAX: 702-399-1431
 8am-5pm Pacific Time
 Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.



3101.001

U.S Models Only

1990-95 Suzuki DR250

Stage 1 & 2


STAGE 1

For mildly tuned machines using the stock airbox, with stock or K&N filter #SU-3590

STAGE 2

For mildly tuned machines using the stock airbox with the airbox lid removed, with stock or K&N filter #SU-3590

Both stages may be used with a good aftermarket exhaust



This graph shows a typical gain with a Dynojet jet kit.

WARNING

**NO SMOKING!
 NO OPEN FLAME!
 WHILE INSTALLING
 YOUR DYNOJET KIT**

Parts List

1	Main Jet	DJ136
1	Main Jet	DJ140
1	Fuel Needle	DNO308
1	E-clip	DE0001
1	Adjusting Washer	DW0001
1	Plug Drill	DD #5/32
1	Screw	DS0001

STAGE ONE & TWO INSTRUCTIONS

DYNOJET
3101.001

Note: For Stage 2 applications, maximize airflow thru the airbox either by modifying or removing the airbox lid.

1. Remove the vacuum slides from the carbs. Remove the stock needles and spacers, noting order of assembly (Fig.A).
2. Install the Dynojet needles on groove #4 from the top. Use all stock spacers (Fig. A). Install the small Dynojet washers above the e-clip. After installing the slides in the carbs be sure to check slide movement manually.
3. Remove the stock main jets and replace with the Dynojet main jets provided. If you are running the stock exhaust install the DJ136 main jets. If you are running an aftermarket exhaust or slip-ons with high flowing baffles use the DJ140 main jets. Be sure that the jet you are changing is the main jet.
4. Locate the fuel mixture plug (Fig. B). If you see a screw head at Fig.B then proceed to the adjusting procedure. With the DD #5/32 drill bit provided carefully drill through the plug. **Note:** The mixture screw is directly underneath this plug, be ready to pull back on the drill the instant you break through. Use screw provided to secure and remove this plug. Carefully turn the mixture screw clockwise until lightly seated, then back out 2-1/2 turns.

