

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
 North Las Vegas, NV 89031
 TEL: 702-399-1423
 FAX: 702-399-1431
 8am-5pm Pacific Time
 Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.



3135.004

U.S Models Only

1990-92 Suzuki GSXR 750

w/ 38mm carbs

Stage 1&3


STAGE 1

For mildly tuned machines using the stock airbox, with stock or K&N filter #SU-7588

STAGE 3

For mildly tuned machines using individual filters or velocity stacks. K&N filters #RU-2922

Both stages may be used with a good aftermarket exhaust



This graph shows a typical gain with a Dynojet jet kit.

WARNING

**NO SMOKING!
 NO OPEN FLAME!
 WHILE INSTALLING
 YOUR DYNOJET KIT**

Parts List		
4	Main Jet	DJ120
4	Main Jet	DJ124
4	Main Jet	DJ155
4	Main Jet	DJ160
4	Fuel Needles	DNO340
4	E-Clips	DE0001
4	Adjusting Washers	DW0001
4	Main Air Jet Plug	DCO400
4	Emulsion Tubes	DET004
4	Slide Orifices	DCO354
1	Tap	DT 8-32
1	Plug Drill	DD #5/32
1	Screw	DS0001

STAGE ONE INSTRUCTIONS

1. Remove the vacuum slides from the carbs. Remove the stock needles and spacers, noting order of assembly (Fig.A).
2. With the tap provided (DT 8-32) tap one slide lift hole on each slide (Fig. A). For street use: Screw the white plastic correctors (DCO354) into the tapped holes. If correctors do not go flush, cut excess off with a razor blade. **NOTE:** For racing or hard street riding you may run all slide lift holes stock for better acceleration
3. Remove the stock main jets. Tap lightly on the emulsion tubes to push them into the carb venturi and remove. Install the Dynojet emulsion tubes (DET004) in place of the stock emulsion tubes (Fig. B).
4. Install the Dynojet main jets provided. If you are running the stock exhaust install the DJ120s. If you are running an aftermarket exhaust or slip-ons with high flowing baffles use the DJ124s. Be sure that the jet you are changing is the main jet.
5. Install the Dynojet needles on groove #2, using all stock spacers (Fig. A). Install the Dynojet washers above the e-clip.
6. Locate the fuel mixture plug (Fig. C). If you see a screw head at Fig.C then proceed to the adjusting procedure. With the 5/32 drill bit provided carefully drill through the plug. **NOTE:** The mixture screw is directly underneath this plug, be ready to pull back on the drill the instant you break through. Use screw provided to secure and remove this plug. Carefully turn the mixture screw clockwise until lightly seated, then back out 2.5 turns.





Fig. A



STAGE THREE INSTRUCTIONS

DYNOJET

3135.004

1. Remove the vacuum slides from the carbs. Remove the stock needles and spacers, noting order of assembly (Fig.A).
2. With the tap provided (DT 8-32) tap one slide lift hole on each slide (Fig. A). For street use: Screw the white plastic correctors (DCO354) into the tapped holes. If correctors do not go flush, cut excess off with a razor blade. **NOTE:** For racing or hard street riding you may run all slide lift holes stock for better acceleration
3. Remove the stock main jets. Tap lightly on the emulsion tubes to push them into the carb venturi and remove. Install the Dynojet emulsion tubes (DET004) in place of the stock emulsion tubes (Fig. B).
4. Install the Dynojet main jets provided. If you are running the stock exhaust install the DJ155s. If you are running an aftermarket exhaust or slip-ons with high flowing baffles use the DJ160s. Be sure that the jet you are changing is the main jet.
5. Install the Dynojet needles on groove #2, using all stock spacers (Fig. A). Install the Dynojet washers above the e-clip.
6. Plug the main air jets with the plugs (DCO400) provided (Fig. D).
7. Locate the fuel mixture plug (Fig. C). If you see a screw head at Fig.C then proceed to the adjusting procedure. With the 5/32 drill bit provided carefully drill through the plug. **NOTE:** The mixture screw is directly underneath this plug, be ready to pull back on the drill the instant you break through. Use screw provided to secure and remove this plug. Carefully turn the mixture screw clockwise until lightly seated, then back out 2.5 turns.

Fig. B




Fig. C




Fig. D

